



Assembly Instructions for Glider and Single Seat Glider

Thank you for purchasing your heirloom quality furniture from Montana Woodworks®. Should you have any questions or need to contact sales or support, please do not hesitate to contact our corporate offices at 888.889.3728 or via E-Mail at: cs@montanawoodworks.com

Tools Needed: 9/16" & 7/16" Wrench or Socket, Rubber Mallet

Before beginning assembly, please take a few moments to carefully read the instructions, familiarize yourself with the components and understand each step of the process. Likewise, please ensure that the hardware package contains the items as described below.

Parts List: (1) Back Assembly, (1) Seat Assembly, (1) Right and Left Arm Assembly, (1) Lower Glide Assembly

Hardware List: (6) 3" Lag Screws, (4) 4" Hex Bolts, (4) Hex Lock Nuts, (14) Washers, (4) Leg Levelers, (2) 4" Screws

Assembly Instructions:

Step 1. Remove components from shipping boxes. You may lay the cardboard on the floor to prevent marring of finish.

Step 2. Place arms "A" onto tenons of seat assembly "B" and back assembly "C".

Step 3. Using rubber mallet, tap arms as required to fully seat arms into holes in seat and back assemblies.

Step 4. Insert lag screws "F" with washers into the pre-drilled side holes and TIGHTEN FULLY.

Step 5. Place completed seat/back/arm assembly over lower glide assembly "D".

Step 6. Insert one bolt through each hole in the 4 pre-attached glide swivels "F".

Step 7. Place one washer on each bolt so there is a washer between the steel glide swivel and the wood surface.

Step 8. Insert one bolt through each of the 4 pre-drilled holes in the lower glide assembly. Place another washer onto each bolt and hand tighten a hex lock nut onto each bolt.

Step 9. Gently glide assembled unit back and forth by hand. *Do not sit on the assembly at this time.*

Step 10. Using socket and wrench(s), tighten lock nuts until snug. Glide assembly must move freely. Do not over tighten.

Step 11. Insert 4" screws into the pre-drilled holes in the back assembly. This step secures the back to the side arms.

Step 12. Insert a leg leveler into each of the four, pre-installed receives on the bottom logs of the lower glide assembly. Adjust each in turn until the glider is level.

Your New Glider is Now Fully Assembled.

PLEASE NOTE: If you purchased your item "ready to finish" special care must be taken to properly apply a high grade final finish in a timely manner. Doing so will help protect your purchase from discoloration and damage caused by exposure to ultra-violet light and/or weather. If the products intended use is outside, please use an exterior rated finish to also protect from weather damage. See use and care instructions for further information. Failure to adequately protect item by application and as needed, re-application of a final finish may void warranty.



Glacier Collection Shown, Other Collections Similar