



Assembly Instructions for Pet Beds

Thank you for purchasing your heirloom quality furniture from Montana Woodworks®. Should you have any questions or need to contact sales or support, please do not hesitate to contact our corporate offices at 888.889.3728 or via E-Mail at: cs@montanawoodworks.com

Tools Needed: 9/16" Wrench and Socket, Rubber Mallet

Before beginning assembly, please take a few moments to carefully read the instructions, familiarize yourself with the components and understand each step of the process. Likewise, please ensure that the hardware package contains the items as described below.

Parts List: (1) Headboard & Footboard Assemblies, (4) Side Rails, (2) Cross Supports, (1) Mattress Support, (1) Mattress, (4) Wooden Hole Plugs

Hardware List: (4) 3" Lag Bolts, (4) Washers

Assembly Instructions:

Step 1. Remove components from shipping boxes. You may lay the cardboard on the floor to prevent marring of finish.

Step 2. Place headboard (headboard & footboard are interchangeable) assembly flat on a non marring surface with holes facing upward.

Step 3. Insert the upper side rails into the upper holes of the headboard

Step 4. Insert the short cross supports into pre-drilled holes in the lower side rails.

Step 5. Position lower side rail/cross support assembly above headboard with tenons facing holes in headboard. Tap ALL side rails gently with rubber mallet until fully seated in headboard

Step 6. Stand headboard/side rail assembly upright.

Step 7. Insert one lag bolt with washer into pre-drilled holes on headboard and tighten until secure.

Step 8. Position footboard at end of side rails.

Step 9. Carefully insert side rails into corresponding holes on footboard.

Step 10. Insert one lag bolt with washer into pre-drilled holes on footboard and tighten until secure.

Step 11. Ensure all lag bolts are tight. Insert a wooden hole plug into each of the headboard/footboard holes and tap gently into place.

Step 12. Place plywood mattress support on top of cross supports. Place mattress on mattress support.

PLEASE NOTE: If you purchased your item "ready to finish" special care must be taken to properly apply a high grade final finish in a timely manner. Doing so will help protect your purchase from discoloration and damage caused by exposure to ultra-violet light and/or weather. If the products intended use is outside, please use an exterior rated finish to also protect from weather damage. See use and care instructions for further information. Failure to adequately protect item by application and as needed, re-application of a final finish may void warranty.