



76 Whitetail Dr. Rexford, MT 59930 888.889.3728
www.montanawoodworks.com cs@montanawoodworks.com

“From The Mountains of Montana to Your Home”

HOW TO INSTALL TIP OVER PREVENTION ANCHORS

INCLUDED HARDWARE: 4 PCS, 1/4" X 4" HEX BOLTS

TOOLS NEEDED: 7/16 SOCKET, 3/8" DRILL BIT, DRILL, TAPE MEASURE

TO ANCHOR YOUR NEW MONTANA WOODWORKS DRESSER TO THE WALL, PLEASE TAKE THE FOLLOWING STEPS.

INSTRUCTIONS:

STEP 1: LOCATE THE STUDS IN THE WALL THAT THE DRESSER WILL BE ANCHORED TO AND MARK STUD LOCATIONS WITH A PENCIL.

STEP 2: PLACE DRESSER IN DESIRED LOCATION AND ADJUST LOCATION ACCORDINGLY TO ALLOW FOR PROPER LOCATION OF ANCHOR HOLES.

STEP 3: TRANSFER STUD LOCATION MARKS ON WALL TO THE BACK OF DRESSER.

STEP 4: REMOVE UPPERMOST DRESSER DRAWER(S).

STEP 5: USING 3/8 DRILL BIT, DRILL HOLES AT MARKED LOCATION THROUGH THE DRESSER BACK.

STEP 6: FROM INSIDE THE DRESSER, INSERT A 1/4" HEX BOLT THROUGH HOLE AND INTO WALL AT MARKED LOCATIONS.

STEP 7: REPEAT AS NECESSARY TO ADEQUATELY SECURE DRESSER TO WALL BUT AT A MINIMUM, 2 ANCHORS MUST BE INSTALLED.

SHOULD YOU HAVE ANY QUESTIONS OR CONCERNS PLEASE CONTACT MONTANA WOODWORKS AT CS@MONTANAWOODWORKS.COM OR TOLL FREE AT 888.889.3728